

## ⚠ WARNING

These instructions are intended to guide qualified service personnel in the placement of critical labels for replacement doors and panels. These labels are vital for the safety, operation and maintenance of the equipment. Equipment must not be placed in operation without doors and panels in place and all appropriate labels affixed.

Product manuals and labels must be read and understood prior to the operation of equipment. Failure to follow product warnings and instructions can result in serious bodily injury or death.

## INSTRUCTIONS:

1. All surfaces should be clean and dry before applying self-adhesive labels.
2. Use the original door as a guide for label placement. If the original door is not available, use the examples provided below for guidance.
3. Some replacement furnaces doors are provided with two ¼ inch diameter holes intended for mounting of a brand badge plate. If this door has these holes and they are not used, they should be filled with the two plugs provided in this kit
4. For further information contact your local distributor or service representative.

## EXAMPLE LABEL PLACEMENT:

