

21105	30BA-1A	30" Propeller - 5/8" bore. Cast Aluminum.	6
21120	24HH-1	24" Propeller, 5/8" bore (use only on 24" high velocity spot coolers.) Galvanized.	7
21130	30HH-1	30" Propeller, 5/8" bore (use only on 30" high velocity spot coolers.) Galvanized.	9
PEDESTAL (Adjustable)			
21152	8CP-2B	5' to 8' pedestal (for use with A786B base.)	14
FLOOR BASE			
21166	A786B-2	For use with 8CP-2 pedestal.	34
WALL BRACKET (15° Tilt Built In)			
21187	878W	Use for HD air circulator wall mountings. Includes Safety Cable Kit.	10
I-BEAM BRACKET			
21191	700-U	Use for HD air circulator I-Beam mountings. Includes Safety Cable Kit.	15
CEILING BRACKET			
21203	CK-2	Use for HD air circulator ceiling mount (non-oscillating only). Extension pipe not included. Includes Safety Cable Kit.	5
ACCESSORIES			
21204	Safety Kit	12' of 1/16" diameter cable, two clamp and instructions. This safety cable kit is available for retrofit applications.	3
12002	DJ-EC-6	6' extension cord - for use with 642-AC2SDP Drop Cord Motor - Yellow	1
12008	DJ-EC-9	9' extension cord - for use with 642-AC2SDP Drop Cord Motor - Yellow	2
12009	DJ-EC-12	12' extension cord - for use with 642-AC2SDP Drop Cord Motor - Yellow	2
70601	AMFW30K 5	Snap on wheel kit with set screw lock for use on all floor model air circulators except I-2030 base. No tools required.	5
01633		15' Cord Replacement	2
01723		2SP/3SP Pull Chain Switch	2

NOTE: Explosion Proof and 3 Phase air circulator motors are not supplied with switches or power cords. Must be hard wired.



© 2008 Airmaster Fan Company

Designed & Powered By: **Digital Dynamic Productions**