

## CO2RT-R Control

0-2000 ppm w/o display, surface mount

Item #: [99315](#)

The CO2RT-R CO2 sensors are used mainly for demand-controlled ventilation to prevent energy losses from over-ventilation while maintaining indoor air quality.

Wall mount sensors are used to control a specific area such as a conference room, classroom, meeting hall, etc. The CO2 sensor is easy to install and has a clean, modern look that suits most indoor environments.

