

## References

Rating (A)	No. of poles	ATyS t <sup>(5)</sup>	Bridging bars	Terminal shrouds	Terminal screens	Auxiliary contact	3 position padlocking	Autotransformer						
125 A	3 P	9543 3012	4109 0019	3 P 2694 3014 <sup>(2)</sup> 4 P 2694 4014 <sup>(2)</sup>	3 P 1509 3012 4 P 1509 4012									
	4 P	9543 4012												
160 A	3 P	9543 3016												
	4 P	9543 4016												
200 A	3 P	9543 3020												
	4 P	9543 4020												
250 A	3 P	9543 3025							4109 0025	3 P 2694 3021 <sup>(2)</sup> 4 P 2694 4021 <sup>(2)</sup>	3 P 1509 3025 4 P 1509 4025	1599 0002 <sup>(4)</sup>	1599 0003 <sup>(4)</sup>	
	4 P	9543 4025												
315 A	3 P	9543 3031							4109 0039					
	4 P	9543 4031												
400 A	3 P	9543 3040												
	4 P	9543 4040												
500 A	3 P	9543 3050	4109 0050	3 P 2694 3051 <sup>(2)</sup> 4 P 2694 4051 <sup>(2)</sup>	3 P 1509 3063 <sup>(3)</sup> 4 P 1509 4063 <sup>(3)</sup>			400/230 VAC 1599 4064						
	4 P	9543 4050												
630 A	3 P	9543 3063	4109 0063											
	4 P	9543 4063												
800 A	3 P	9543 3080	4109 0080							3 P 1509 3080 <sup>(3)</sup> 4 P 1509 4080 <sup>(3)</sup>				
	4 P	9543 4080												
1000 A	3 P	9543 3100												
	4 P	9543 4100												
1250 A	3 P	9543 3120	4109 0120											
	4 P	9543 4120												
1600 A	3 P	9543 3160	4109 0160		3 P 1509 3160 <sup>(3)</sup> 4 P 1509 4160 <sup>(3)</sup>									
	4 P	9543 4160												
1800 A	3 P	9543 3180												
	4 P	9543 4180												
2000 A	3 P	9543 3200	(1)											
	4 P	9543 4200												
2500 A	3 P	9543 3250												
	4 P	9543 4250												
3200 A	3 P	9543 3320												
	4 P	9543 4320												

(1) See "Copper bar connection kits" page 393.

(2) To fully shroud front, rear, top and bottom 4 references required.  
To shroud front switch top and bottom 2 references required.

(3) 2 pieces: one for top side and another for bottom side.

(4) Factory mounting only.

(5) An optional key operated Auto/Manual selector is available on request.  
If required, this option must be requested when ordering the switch;  
please refer to "Auto/Manual key selector" in the accessory section.

### Technical information

- > Accessories: see page 392.
- > Characteristics: see page 398.
- > Terminals and connections: see page 400.
- > Dimensions: see page 402.