

## References

Rating (A)	No. of poles	ATyS p <sup>(5)</sup>	Bridging bars	Terminal shrouds	Terminal screens	Optional modules	Auxiliary contact	Autotransformer															
125 A	3 P	9573 3012	4109 0019	3 P 2694 3014 <sup>(2)</sup> 4 P 2694 4014 <sup>(2)</sup>	3 P 1509 3012 4 P 1509 4012																		
	4 P	9573 4012																					
160 A	3 P	9573 3016																					
	4 P	9573 4016																					
200 A	3 P	9573 3020																					
	4 P	9573 4020																					
250 A	3 P	9573 3025							4109 0025	3 P 2694 3021 <sup>(2)</sup> 4 P 2694 4021 <sup>(2)</sup>	3 P 1509 3025 4 P 1509 4025		1599 0002 <sup>(4)</sup>										
	4 P	9573 4025																					
315 A	3 P	9573 3031																					
	4 P	9573 4031																					
400 A	3 P	9573 3040	4109 0039	3 P 2694 3051 <sup>(2)</sup> 4 P 2694 4051 <sup>(2)</sup>	3 P 1509 3063 <sup>(3)</sup> 4 P 1509 4063 <sup>(3)</sup>	RS485 JBUS/ MODBUS communication 4825 0092																	
	4 P	9573 4040																					
500 A	3 P	9573 3050																					
	4 P	9573 4050																					
630 A	3 P	9573 3063	4109 0063						3 P 2694 3051 <sup>(2)</sup> 4 P 2694 4051 <sup>(2)</sup>						3 P 1509 3063 <sup>(3)</sup> 4 P 1509 4063 <sup>(3)</sup>	2 inputs / 2 outputs 4825 0094							
	4 P	9573 4063																					
800 A	3 P	9573 3080	4109 0080							3 P 2694 3051 <sup>(2)</sup> 4 P 2694 4051 <sup>(2)</sup>	3 P 1509 3063 <sup>(3)</sup> 4 P 1509 4063 <sup>(3)</sup>	Ethernet communication 4825 0203											
	4 P	9573 4080																					
1000 A	3 P	9573 3100																					
	4 P	9573 4100																					
1250 A	3 P	9573 3120	4109 0120	3 P 2694 3051 <sup>(2)</sup> 4 P 2694 4051 <sup>(2)</sup>	3 P 1509 3080 <sup>(3)</sup> 4 P 1509 4080 <sup>(3)</sup>	Ethernet communication + RS485 MODBUS gateway 4825 0204																	
	4 P	9573 4120																					
1600 A	3 P	9573 3160	4109 0160																3 P 2694 3051 <sup>(2)</sup> 4 P 2694 4051 <sup>(2)</sup>	3 P 1509 3080 <sup>(3)</sup> 4 P 1509 4080 <sup>(3)</sup>	Analogue outputs 4825 0093		
	4 P	9573 4160																					
1800 A	3 P	9573 3180																					
	4 P	9573 4180																					
2000 A	3 P	9573 3200	(1)						3 P 2694 3051 <sup>(2)</sup> 4 P 2694 4051 <sup>(2)</sup>	3 P 1509 3160 <sup>(3)</sup> 4 P 1509 4160 <sup>(3)</sup>	Pulse outputs 4825 0090	1599 0032 <sup>(4)</sup>											
	4 P	9573 4200																					
2500 A	3 P	9573 3250																					
	4 P	9573 4250																					
3200 A	3 P	9573 3320																					
	4 P	9573 4320																					

(1) See "Copper bar connection kits" page 393.

(2) To fully shroud front, rear, top and bottom 4 references required.

To shroud front switch top and bottom 2 references required.

(3) 2 pieces: one for top side and another for bottom side.

(4) Factory mounting only.

(5) An optional key operated Auto/Manual selector is available on request.

If required, this option must be requested when ordering the switch;

please refer to "Auto/Manual key selector" in the accessory section.